

AUTO SPRING KITS

REAR LIFT BLOCK INSTALLATION INSTRUCTIONS

2005-2007 NISSAN FRONTIER 2WD OR 4WD

TOOLS REQUIRED

**FLOOR JACK
JACK STANDS
METRIC AND US SOCKETS
TORQUE WRENCH**

WWW.AUTOSPRINGCORP.COM

TECH SUPPORT CONTACT

1-800-345-0431

FAX

208-362-6310

ADDRESS

**8007 W. MOSSY CUP ST
BOISE, IDAHO 83709**

1. Before beginning, read the instructions completely.
2. Jack up the rear of the vehicle enough to lift the rear tires off the ground and support frame with jack stands
3. Remove the rear tires.
4. Place floor jack under rear axle housing and support rear-end.
5. Remove factory u-bolts on one side only.
6. Lower the rear end housing with floor jack to allow the spring to separate from the axle spring seat. Lower the rear end 3 inches between the spring and axle seat to allow install of the 1-1/2" spacer blocks.
7. Install lift block provided on axle spring seat with thicker portion of the block towards the rear of the vehicle.
8. Jack rear end up enough to allow the spring centerbolt head to fit in block centering hole.
9. Install new u-bolts provided and torque nuts to 75 ft. lbs.
10. Repeat install procedure on opposite side.
11. Re-install rear tires and tighten lug nuts and carefully lower the vehicle to the ground.
12. Re-torque the lug nuts to factory OEM specs.

Re-torque all nuts after 300 miles